


# Repeater




The LifeShield Repeater expands the wireless coverage of your LifeShield System. You should use a Repeater to add sensors to areas which are more than 30 feet away from the LifeShield Base. We recommend you use a Repeater for larger homes to ensure that your home and loved ones are protected.



To add a Repeater to your system using your Security Touchpad follow the instructions below.

## ADDING THE REPEATER

- 1) Remove the back of the Repeater by pressing on the tab and separating
- 2) Remove battery tab/Insert the battery
- 3) Snap the back plate back onto the Repeater
- 4) Using the power cord provided plug into the back of the Repeater
- 5) Plug the power cord into a power outlet
- 6) On your security touchpad go to Settings (enter Master Code if prompted) → Devices → Select the Add button [+] → Select Repeater from the dropdown Menu and Click [+] Add
- 7) Follow the instructions on your Touchpad to complete the Adding Process



## PLACING THE REPEATER

**Tip: the Repeater must be within 30ft of the Base**

### **Table**

- 1) No assembly needed, just place on the desired table

### **Wall**

- 1) Remove the back plate of the Repeater by pressing on the tab and separating
- 2) Mount the back plate to the wall using the screws provided
- 3) Snap the back plate back onto the Repeater

If you have any questions, you can reach us at (877) 232-1616.